



Palma Dental  
Laboratory

37 Industrial Park Road  
Plymouth, MA 02360  
palmadentallab.com  
Tel: 803-962-7587

# Turn Around Times

In Lab Working Days

## CROWN & BRIDGE

	<u>Standard</u>	<u>Rush</u>
Full Gold Crown	8-10 Days	1-2 Days
Full Contour Zirconia	8-10 Days	1-2 Days
eMax Pressed Ceramic	8-10 Days	1-2 Days
High Translucent Zirconia	8-10 Days	3 Days
Zirconia Layered	8-10 Days	3 Days
eMax Layered	8-10 Days	3 Days
eMax Veneer	8-10 Days	3 Days
Zirconia Layered	8-10 Days	3-4 Days
PFM	8-10 Days	1-2 Days
eMax inlay/onlay	8-10 Days	3 Days
PFM Maryland Bridge- 1 pontic, 2 wings	8-10 Days	3 Days
eMax Maryland Bridge- 1 pontic, 2 wings	8-10 Days	3 Days
Zirconia Maryland Bridge- 1 pontic, 2 wings	8-10 Days	3 Days

## IMPLANTS

Custom Abutment & Implant Crown	10-14 Days	8-10 Days
Screw Retained Zirconia on ti-Base	10-14 Days	8-10 Days
All on X, Final Only		
Full Zirconia	10-14 Days	8-10 Days
Titanium Bar with Zirconia	10-14 Days	8-10 Days
Titanium Bar with Acrylic	10-14 Days	8-10 Days
All on X, Nexus Final	4 Weeks	N/A



Palma Dental Lab



info@palmadentallabs.com



Palma Dental  
Laboratory

37 Industrial Park Road  
Plymouth, MA 02360  
palmadentallab.com  
Tel: 803-962-7587

# Turn Around Times

In Lab Working Days

## SURGICAL GUIDES

Surgical Guide

1-3 implants

**8-10 Days**

**2-5 Days**

Over 3 Implants

**8-10 Days**

**2-5 Days**

## REMOVABLE 1

Full Complete Denture

Set Up

**7 Days**

**5 Days**

Process

**7 Days**

**5 Days**

Acrylic Partial Complete, 1-4 Teeth

Set Up

**7 Days**

**5 Days**

Process

**7 Days**

**5 Days**

Acrylic Partial Complete, 5+ Teeth

Set Up

**7 Days**

**5 Days**

Process

**7 Days**

**5 Days**

Cast Partial Complete

Metal Framework

**10-12 Days**

**10 Days**

Set Up

**7 Days**

**5 Days**

Process

**7 Days**

**5 Days**

Valplast Partial Complete

Set Up

**7 Days**

**3 Days**

Process

**10 Days**

**N/A**



Palma Dental Lab



info@palmadentallabs.com



Palma Dental  
Laboratory

37 Industrial Park Road  
Plymouth, MA 02360  
palmadentallab.com  
Tel: 803-962-7587

# Turn Around Times

In Lab Working Days

## REMOVABLE 2

	<u>Standard</u>	<u>Rush</u>
Flipper, 1-3 Teeth	7 Days	2 Days
Valplast Nesbit	10 Days	N/A
Hard / Soft Night Guard	7 Days	2 Days
Essix Retainer	7 Days	2 Days
Custom Tray	5 Days	1-2 Days
Bite Block	5 Days	1-2 Days
Reset	5 Days	2-3 Days
Denture / Partial Repair	1-2 Days	1-2 Days
Hard Reline	1-2 Days	1-2 Days
Soft Reline	1-2 Days	1-2 Days
Overdenture with Locators		
Custom Tray	5 Days	1-2 Days
Wax Rim	5 Days	1-2 Days
Set Up	7 Days	5 Days
Process	7 Days	5 Days
Overdenture with Locators, Parts Provided		
Custom Tray	5 Days	1-2 Days
Wax Rim	5 Days	1-2 Days
Set Up	5-7 Days	5 Days
Process	5-7 Days	5 Days



Palma Dental Lab



info@palmadentallabs.com